

JEEP WRANGLER TJ REAR BUMP STOP SPACER KIT

Part Number FK16

CONTENTS:

Quantity	Description
2	Spacer – Bump Stop 20mm

FITTING INSTRUCTIONS:

- Remove both rear bump stops from chassis.
- Place OME bump stop spacers between chassis and original bump stop rubber retaining cups and install using original bolts.
- Retighten bolts securely.

(Refer overleaf for diagram)

