




FORD RANGER PX 2012 on PERIMETER ALARM FITMENT TO CONSOLE

For transfer of Perimeter Sensor from Light Pod to Outback Roof Console, you will need the following items: small thin blade screwdriver, marking pen, electric or battery drill, 3mm and 10mm drill bit, 100mm length of sticky backed Velcro tape and a small tube of Cyanoacrylate super-glue.


1. Use a small blade screwdriver to push the upper 4 tabs inwards to separate black sensor pack from the light Pod assembly.
2. Push the lower 4 tabs inwards to separate the lower assembly from frame, and to gain access to captive sensors.
3. Slide sensor pick-up wires out from plastic clasps situated each side of lower assembly.
4. Lift out thin wire running across lower assembly.
5. Using thin screwdriver, gently put pressure on one pick-up sensor tab while carefully pulling on wire to remove from frame. Remove other sensor from frame. Sensor Pack is now freed from assembly.
6. Clean inside front area of console radio opening with white spirits or similar for Velcro and super-glue to adhere to.
7. Place ++ sticky back Velcro above radio opening, and the -- sticky back Velcro to Sensor Pack.
8. Mark a straight line on side edge of console LED light housing towards radio opening, and drill a 3mm pilot hole, followed by 10mm hole in the centre flat area, on each side. Drill holes through console from inside. De-burr all drilled holes.
9. Press Sensor Pack onto Velcro with wires from Pack facing towards LED lights and harness plug opening facing down. Poke the two sensor pick-ups into 10mm holes. Have approx. 1-2mm of sensor protruding out from console body, then run a bead of super-glue on the inside of console around sensor pick-up. Allow glue to set hard before console installation.
10. While holding console up next to front mount bracket when installing, re-connect vehicle green connector plug into sensor pack along with Bluetooth Mic pick-up plug into vehicle loom. Perimeter sensor will now function as intended.



STEPS 1-5



STEPS 1-5



STEPS 1-5



STEPS 1-5



STEPS 1-5



STEPS 6-9



STEPS 6-9



STEPS 6-9



STEPS 6-9



STEPS 6-9



STEPS 6-9



10